



iPhone 7 Pentalobe Screws Replacement

Remove or replace the pentalobe screws in an iPhone 7.

Written By: Evan Noronha



INTRODUCTION

Follow the steps in this guide to remove or replace the Pentalobe screws in an iPhone 7.



TOOLS:

- [P2 Pentalobe Screwdriver iPhone](#) (1)





PARTS:

- [iPhone 7/7 Plus Bottom Screws](#) (1)

Step 1 — Pentalobe Screws



-  Before you begin, discharge your iPhone battery below 25%. A charged lithium-ion battery can catch fire and/or explode if accidentally punctured.
- Power off your iPhone before beginning disassembly.
-  Opening the iPhone's display will damage its waterproof seals. If you do not replace the seals, your phone will no longer be water resistant.
- Remove the two 3.4 mm pentalobe screws on the bottom edge of the iPhone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-21 05:11:50 PM.